





CK 30600

9PIN SCART PLUG TO 9PIN
SCART PLUG ELECTRONIC
CABLE
O.D.:7.0MM





CK 30601

9PIN SCART PLUG TO 9PIN
SCART JACK ELECTRONIC
CABLE
O.D.:7.0MM




CK 30602

21PIN SCART PLUG TO 9PIN
21PIN SCART PLUG CABLE
A:O.D.7.0MM
B:O.D.8.0MM
C:O.D.10.0MM





CK 30603

21PIN SCART PLUG TO 9PIN
21PIN SCART PLUG
STANDARD CABLE
O.D.:10.3mm



CK 30604

21PIN SCART PLUG TO 2 ×
21PIN SCART PLUGS
CABLE
O.D.:7.0 × 14.0MM



CK 30605

21PIN SCART PLUG TO
2RCA PLUGS CABLE
A:O.D.:7.0 MM
B:O.D.:2.8 × 5.6MM



SCART CABLE




CK 30606

21PIN SCART PLUG TO
3RCA PLUGS CABLE
A.O.D.:7.0 MM
B.O.D.:2.8 × 8.4MM




CK 30607

21PIN SCART PLUG TO
4RCA PLUGS CABLE
A.O.D.:8.0 MM
B.O.D.:2.8 × 11.2MM




CK 30608

21PIN SCART PLUG TO
6RCA PLUGS CABLE
A.O.D.:9.0 MM
B.O.D.:2.8 × 16.8MM




CK 30609

21PIN SCART PLUG TO
4RCA PLUGS CABLE
O.D.:5.0 MM





CK 30610

21PIN SCART PLUG TO 2RCA
PLUGS CABLE W/SWITCH
A.O.D.:7.0 MM
B.O.D.:2.8 × 5.6MM




CK 30611

21PIN SCART PLUG TO 3RCA
PLUGS CABLE W/SWITCH
A.O.D.:7.0 MM
B.O.D.:2.8 × 8.4MM







CK 30612
 9PIN SCART PLUG TO 9PIN
 SCART PLUG FLAT
 STANDARD CABLE
 O.D.:2.2 × 17.6MM



CK 30613
 21PIN SCART PLUG TO
 21PIN SCART PLUG FLAT
 STANDARD CABLE
 O.D.:2.2 × 28.6MM




CK 30614
 21PIN SCART PLUG TO
 2 RCA PLUGS FLAT
 STANDARD CABLE
 O.D.:2.8 × 5.6MM




CK 30615
 21PIN SCART PLUG TO
 3 RCA PLUGS FLAT
 STANDARD CABLE
 O.D.:2.8 × 8.4MM



CK 30616
 21PIN SCART PLUG TO
 4 RCA PLUGS FLAT
 STANDARD CABLE
 O.D.:2.8 × 11.2MM



CK 30617
 21PIN SCART PLUG TO
 6 RCA PLUGS FLAT
 STANDARD CABLE
 O.D.:2.8 × 16.8MM





CK 30618
 FT318 20+1 cable
 FT318B 9+1 cable
 Moulded 21 PIN Plug to Plug
 scart(120°) Assembled Nicki-
 plated Metal shell.

Diagram showing a 21-pin SCART connector with a diameter of 12.5mm.

CK 30624
 Moulded 21 PIN Plug Scart
 (120°) to 2×RCA Plug Plus S-VHS Plug
 Assembled Nickel- Plated Metal Shell.
 -IN:Video In; -OUT:Video Out;

Diagram showing a 21-pin SCART connector with a diameter of 14mm, connected to two RCA plugs and one S-VHS plug.

CK 30619
 Moulded 21 PIN Plug Scart
 (120°) to RCA Plug Assembled
 Nickel- Plated Metal Shell.
 -IN/A:Audio In;-OUT/A:Audio Out;
 -IN/A:Video In;-OUT/A:Audio Out;

Diagram showing a 21-pin SCART connector with a diameter of 12mm, connected to one RCA plug.

CK 30625
 Moulded 21 PIN Plug Scart
 (120°) to S-VHS Plug
 Assembled Nickel- Plated Metal Shell.
 -IN:Video In; -OUT:Video Out;

Diagram showing a 21-pin SCART connector with a diameter of 12mm, connected to one S-VHS plug.

CK 30620
 Moulded 21 PIN Plug Scart
 (120°) to RCA Plug Assembled
 Nickel- Plated Metal Shell.
 -IN/A:2-Audio In;-OUT/A:2-Audio Out;
 -IN/A:AV In;-OUT/AV:AV Out;

Diagram showing a 21-pin SCART connector with a diameter of 12mm, connected to two RCA plugs.

CK 30626
 Moulded 21 PIN Plug Scart
 (120°) With Switch to 2×RCA Plug
 Assembled Nickel- Plated Metal Shell.
 /A:2-Audio I/O; /AV:AV I/O

Diagram showing a 21-pin SCART connector with a diameter of 12mm, connected to two RCA plugs via a switch.

CK 30621
 Moulded 21 PIN Plug Scart
 (120°) to 3×RCA Plug Assembled
 Nickel- Plated Metal Shell.
 -IN:AV In; -OUT:AV Out;

Diagram showing a 21-pin SCART connector with a diameter of 14mm, connected to three RCA plugs.

CK 30627
 Moulded 21 PIN Plug Scart
 (120°) With Switch to 3×RCA Plug
 Assembled Nickel- Plated Metal Shell.

Diagram showing a 21-pin SCART connector with a diameter of 14mm, connected to three RCA plugs via a switch.

CK 30622
 Moulded 21 PIN Plug Scart
 (120°) to 4×RCA Plug Assembled
 Nickel- Plated Metal Shell.
 /A:Audio I/O
 /AV:2-Audio & 2-video I/O

Diagram showing a 21-pin SCART connector with a diameter of 10mm, connected to four RCA plugs.

CK 30628
 Moulded 21 PIN Plug Scart
 (120°) With Switch to 4×RCA Plug
 Plus 2×S-VHS Plug Assembled
 Nickel- Plated Metal Shell.

Diagram showing a 21-pin SCART connector with a diameter of 14mm, connected to four RCA plugs and two S-VHS plugs via a switch.

CK 30623
 Moulded 21 PIN Plug Scart
 (120°) to 6×RCA Plug Assembled
 Nickel- Plated Metal Shell.

Diagram showing a 21-pin SCART connector with a diameter of 15mm, connected to six RCA plugs.


CK 30629
 Moulded 21 PIN Plug Scart
 (120°) With Switch to 2×RCA Plug
 Plus S-VHS Plug Assembled
 Nickel- Plated Metal Shell.

Diagram showing a 21-pin SCART connector with a diameter of 14mm, connected to two RCA plugs and one S-VHS plug via a switch.



CK 30630

Moulded 21 PIN Plug to plug
Scart(180°) Assembled
Nickel- Plated Metal Shell.



CK 30636

Moulded 21 PIN Plug Scart(180°)
to 2× RCA plug and S-VHS Plug
Assembled Nickel-Plated Metal Shell
-IN:AV In; -OUT:AV Out



CK 30631

Moulded 21 PIN Plug Scart(180°)
to RCA plug Assembled
Nickel- Plated Metal Shell.
-IN/A:Audio In;-OUT/A:Audio Out
-IN/V:Audio In;-OUT/AV:Audio Out



CK 30637

Moulded 21 PIN Plug Scart(180°)
to S-VHS plug Assembled
Nickel-Plated Metal Shell
-IN:Video In; -OUT:Video Out




CK 30632

Moulded 21 PIN Plug Scart(180°)
to 2× RCA plug Assembled
Nickel- Plated Metal Shell.
-IN/A:Audio In;-OUT/A:Audio Out
-IN/AV:AV In;-OUT/AV:AV Out;



CK 30638

Moulded 21 PIN Plug Scart(180°)
With Switch to 2× RCA Plug
Assembled Nickel-Plated Metal Shell
/A:2-Audio In; /AV:AV I/O



CK 30633

Moulded 21 PIN Plug Scart(180°)
to 3× RCA plug Assembled
Nickel- Plated Metal Shell.
-IN/AV:AV In;-OUT/AV:AV Out;



CK 30639

Moulded 21 PIN Plug Scart(180°)
With Switch to 3× RCA Plug
Assembled Nickel-Plated Metal Shell




CK 30634

Moulded 21 PIN Plug Scart(180°)
to 4× RCA plug Assembled
Nickel- Plated Metal Shell.
/AV:2-Audio & 2-Video I/O;
/A:Audio I/O



CK 30640

Moulded 21 PIN Plug Scart(180°)
With Switch to 4× RCA Plug
pLUG 2×S-VHS Plug
Assembled Nickel-Plated Metal Shell



CK 30635

Moulded 21 PIN Plug Scart(180°)
to 6× RCA plug Assembled
Nickel- Plated Metal Shell.



CK 30641


Moulded 21 PIN Plug Scart(180°)
With Switch to 2× RCA Plug Plus
S-VHS Plug Assembled
Nickel-Plated Metal Shell






CK 30642

21 PIN Plug to PlugScart(120°)
Assembled Nickel-Plated
Plastic Shell



CK 30648


21 PIN Plug Scart(120°) to 2×RCA
Plug plus S-VHS Plug Assembled
Nickel-Plated Plastic Shell.



CK 30643

21 PIN Plug Scart(120°) to RCA
Plug Assembled Nickel-Plated
Plastic Shell.

-IN/A:Audio In;-OUT/A:Audio Out;
-IN/A:Audio In;-OUT/v:Audio Out;



CK 30649

21 PIN Plug Scart(120°) to S-VHS
Plug Assembled Nickel-Plated
Plastic Shell.


-IN:Video In;- -OUT:Video Out;



CK 30644

21 PIN Plug Scart(120°) to 2×RCA
Plug Assembled Nickel-Plated
Plastic Shell.

-IN/A:2-Audio In;-OUT/A:2-Audio Out;
-IN/A:AV In;-OUT/v:AV Out;



CK 30650

21 PIN Plug Scart(120°) With Switch
to 2×RCA Plug Assembled
Nickel-Plated Plastic Shell.


/A:2-Audio I/O; /AV:AV I/O



CK 30645


21 PIN Plug Scart(120°) to 3×RCA
Plug Assembled Nickel-Plated
Plastic Shell.

-IN/A:AV In;-OUT/v:AV Out;



CK 30651

21 PIN Plug Scart(120°) With Switch
to 3×RCA Plug Assembled
Nickel-Plated Plastic Shell.



CK 30646


21 PIN Plug Scart(120°) to
4×RCA Plug Assembled
Nickel-Plated Plastic Shell.

/A:Audio I/O
/AV:2-Audio & 2-Video I/O




CK 30652

21 PIN Plug Scart(120°) With
Switch to 4×RCA Plug Plus
2× S-VHS Plug Assembled
Nickel-Plated Plastic Shell.




CK 30647

21 PIN Plug Scart(120°) to
6×RCA Plug Assembled
Nickel-Plated Plastic Shell.




CK 30653

21 PIN Plug Scart(120°) With
Switch to 2×RCA Plug Plus
S-VHS Plug Assembled
Nickel-Plated Plastic Shell.







CK 30654
 21PIN SCART PLUG TO 2 × 21PIN SCART JACKS BOX (MINI TYPE)
 O.D.:7.0MM L:0.5M



CK 30655
 21PIN SCART PLUG TO 3 × 21PIN SCART JACKS BOX (MINI TYPE)
 O.D.:7.0MM L:0.5M




CK 30656
 21PIN SCART PLUG TO 5 × 21PIN SCART JACKS BOX (MINI TYPE)
 O.D.:7.0MM L:0.5M




CK 30657
 21PIN SCART PLUG TO 2 × 21PIN SCART JACKS BOX
 O.D.:8.0MM L:0.5M



CK 30658
 21PIN SCART PLUG TO 3 × 21PIN SCART JACKS BOX
 O.D.:8.0MM L:0.5M




CK 30659
 21PIN SCART PLUG TO 5 × 21PIN SCART JACKS BOX
 O.D.:8.0MM L:0.5M






CK 30660

21PIN SCART PLUG TO 21PIN SCART JACK AND 3RCA JACKS AND 1 MINI 4PIN JACK (W/SWITCH) O.D.:7.0MM L:0.5M




CK 30661

21PIN SCART PLUG TO × 21PIN SCART JACK AND BOX (W/SWITCH) O.D.:7.0MM L:0.5M




CK 30662

3×21PIN SCART PLUG TO 3RCA JACKS (W/SWITCH) O.D.:7.0 × 21.0MM L:0.5M




CK 30663

21PIN SCART PLUG TO 3 × 21PIN SCART JACKS BOX (W/3 SWITCH) O.D.:7MM L:0.4M




CK 30664

21PIN SCART PLUG TO 3 × 21PIN SCART JACKS AND 2RCA JACKS (W/3 SWITCH) O.D.:7MM L:0.4M




CK 30665

21PIN SCART PLUG TO 2 × 21PIN SCART JACKS AND 2RCA JACKS BOX O.D.:8.0MM L:0.4M







CK 30666
21PIN SCART PLUG TO 2 × 21PIN SCART JACKS AND 2RCA JACKS BOX W/SWITCH
O.D.:8.0MM L:0.5M



CK 30667
21PIN SCART PLUG TO 2 × 21PIN SCART JACKS AND 3RCA JACKS BOX
O.D.:8.0MM L:0.5M




CK 30668
21PIN SCART PLUG TO 2 × 21PIN SCART JACKS AND 3RCA JACKS BOX W/SWITCH
O.D.:8.0MM L:0.5M



CK 30669
21PIN SCART PLUG TO 2 × 21PIN SCART JACKS AND 3RCA JACKS AND 1 MINI 4PIN JACK
O.D.:8.0MM L:0.5M



CK 30670
21PIN SCART PLUG TO 2 × 21PIN SCART JACKS AND 3RCA JACKS AND 1 MINI 4PIN JACK W/SWITCH
O.D.:8.0MM L:0.5M



CK 30671
21PIN SCART PLUG TO 2 × 21PIN SCART JACKS BOX W/SWITCH
O.D.:8.0MM L:0.5M





CK 30672
1-2 SCART SPLITTER
LENGTH:0.5M



FEATURES:
★ SCAFT PLUG-2 × SCART SCKETS

CK 30675
1-2 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCAFT PLUG-2 × SCART SCKE WITH 3RCA JACKS

CK 30673
1-2 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCAFT PLUG-2 × SCART SCKETS WITH SWITCH

CK 30676
1-2 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCAFT PLUG-2 × SCART SCKETS WITH 3RCA AND S-VHS JACKS

CK 30674
1-2 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCAFT PLUG-2 × SCART SCKETS WITH 2RCA JACKS

CK 30677
1-2 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCAFT PLUG-2 × SCART SCKETS WITH 3RCA AND S-VHS JACKS WITH SWITCH



CK 30678
1-3 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCART PLUG-3 × SCART SCKETS

CK 30681
1-3 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCART PLUG-3 × SCART SCKETS
WITH 3RCA AND S-VHS JACKS WITH SWITCH

CK 30679
1-3 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCART PLUG-3 × SCART
SCKETS WITH SWITCH

CK 30682
1-5 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCART PLUG-5 × SCART SCKETS

CK 30680
1-3 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCART PLUG-3 × SCART
SCKETS WITH 2RCA JACKS

CK 30683
1-5 SCART SPLITTER
LENGTH: 0.5M



FEATURES:
★ SCART PLUG-5 × SCART
SCKETS WITH SWITCH



CK 30684
SCART ADAPTER
SCART PLUG TO 2 × RCA
JACKS (AUDIO IN)



CK 30690
SCART ADAPTER
SCART PLUG TO
2 × RCA JACKS (AUDIO IN)



CK 30685
SCART ADAPTER
SCART PLUG TO 2 × RCA
JACKS (AUDIO OUT)



CK 30691
SCART ADAPTER
SCART PLUG TO
2 × RCA JACKS (AUDIO IN)



CK 30686
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS (AUDIO IN)



CK 30692
SCART ADAPTER
SCART PLUG TO
3 × RCA JACKS (AUDIO IN)



CK 30687
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS (AUDIO OUT)



CK 30693
SCART ADAPTER
SCART PLUG TO
3 × RCA JACKS (AUDIO OUT)



CK 30688
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS WITH SWITCH



CK 30694
SCART ADAPTER
SCART PLUG TO
3 × RCA JACKS WITH SWITCH



CK 30689
SCART ADAPTER
SCART PLUG TO
3 × RCA AND S-VHS
JACKS WITH SWITCH



CK 30695
SCART ADAPTER
SCART PLUG TO
3 × RCA AND S-VHS
WITH SWITCH






CK 30696
SCART PLUG (MALE)




CK 30702
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS (AUDIO IN)



CK 30697
SCART PLUG (FEMALE)




CK 30703
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS (AUDIO OUT)



CK 30698
SCART PLUG
AUDIO/VIDEO OUT




CK 30704
SCART ADAPTER
SCART PLUG TO 2RCA
JACKS WITH SWITCH



CK 30699
SCART PLUG
AUDIO/VIDEO IN



CK 30705
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS WITH SWITCH



CK 30700
SCART ADAPTER
SCART PLUG TO 2 × RCA
JACKS (AUDIO IN)



CK 30706
SCART ADAPTER
SCART PLUG TO
3 × RCA AND S-VHS
JACKS WITH SWITCH



CK 30701
SCART ADAPTER
SCART PLUG TO 2 × RCA
JACKS (AUDIO OUT)



CK 30707
SCART ADAPTER
SCART PLUG TO
2 × RCA JACKS (AUDIO IN)






CK 30708
SCART ADAPTER
SCART PLUG TO 2 × RCA
JACKS (AUDIO OUT)




CK 30714
SCART PLUG TO
3 RCA JACKS OUT
+SCART JACK




CK 30709
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS (AUDIO IN)



CK 30715
SCART PLUG TO
3 RCA JACKS OUT
MINI TYPE




CK 30710
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS (AUDIO OUT)



CK 30716
SCART PLUG TO
3 RCA JACKS OUT




CK 30711
SCART ADAPTER
SCART PLUG TO 3 × RCA
JACKS WITH SWITCH



CK 30717
SCART PLUG TO
3 RCA JACKS IN



CK 30712
SCART ADAPTER
SCART PLUG TO
3 × RCA AND S-VHS
JACKS WITH SWITCH



CK 30718
SCART PLUG TO
SCART JACK AND
3 RCA JACKS



CK 30713
SCART PLUG TO
3 RCA JACKS IN
+SCART JACK



CK 30719
SCART PLUG TO
SCART JACK WITH
3 RCA JACKS AND
MINI 4PIN JACK






CK 30720
21PIN SCART PLUG TO
21PIN SCART JACK AND
3.5MM STEREO JACK




CK 30726
SCART-PLUG TO
SCART-JACK
+3 × RCA JACK
+4 PIN HOSEN-JACK
AUDIO:STEREO
RCA JACKS WITH SWITCH
IN/OUT 0.4M




CK 30721
21PIN SCART PLUG TO
21PIN SCART JACK AND
2RCA JACK



CK 30727
SWITCH BOX FOR
CONNECTING A
SATELLITE-RECEIVER
WITH A VIDEO-RECORDER
AND A
TV-SET.ADDITIONAL
VIDEO AND
AUDIO STEREO OUTPUT.




CK 30722
21PIN SCART PLUG TO
21PIN SCART JACK AND
3RCA JACK



CK 30728
SCART VIDEO CONTROL



CK 30723
SCART JACK TO SCART JACK



CK 30729
SATELLITE DECODER
CONTROL CONNECTS
2 EXTERNAL
DECODERS TO YOUR
SATELLITE RECEIVER
VIA SELECTOR SWITCH.




CK 30724
VIDEO 2-WAY RECORDING
DISTRIBUTOR TO ONE TV
W/21 PIN SCART JACK
0.5M CABLE



CK 30730
AV-SWITCH S-VHS



CK 30725
SCART-CONNECTING
CABLE
SCART MALE TO
3 × SCART FEMALE AND
2RCA 1M CABLE



CK 30731
2 SCART JACKS
ADAPTOR





CK 30732

SCART SWITCH BOX FOR S-VHS, Hi8 FOR RECORDING FROM VIDEORECORDER 1 TO 2 OR FROM 2 TO 1 WITH SEPARATE MONITOR CONTROL. ADDITIONAL AUDIO STEREO OUTPUT.




CK 30738

AUTO SCART



CK 30733

AUDIO-VIDEO CONTROL CENTRE



CK 30739

ROUND A/V SWITCHER
3 × INPUTS




CK 30734

3 WAY AUDIO-VIDEO INPUT CONTROL



CK 30740

GAME SELECTOR




CK 30735

SCART SWITCH BOX
3 SCART INPUT JACK
1 SCART OUTPUT JACK
W/2 RCA SOCKETS



CK 30741

GAME SELECTOR



CK 30736

SCART SWITCH BOX
3 SCART INPUT JACK
1 SCART OUTPUT JACK
W/4 RCA SOCKETS



CK 30742

BASIC VIDEO SWITCHER
3 × INPUTS



CK 30737

SCART SWITCH BOX
3 SCART INPUT JACK
1 SCART OUTPUT JACK
W/6 RCA SOCKETS
A: PLASTIC BOX
B: METAL BOX



CK 30743

AV GAME SELECTOR
3 × INPUTS

